

# FVO-1000TR – PARTS LIST

## HARDWARE

**DOOR LATCH ASSEMBLY**



**FMA-2312**

**BOLT ON HINGE**



**FV-450TR**

**PUSH TO CLOSE**



**FV-443TR**

**LOCKING DOOR LATCH/ ROD**



**FV-465TR**

**BALL HITCH**



**FVO-437TR**

**PINTLE HITCH**



**FVO-438TR**

**SUPPORT JACK**



**FVO-435TR**

**EMERGENCY BREAKAWAY KIT**



**FV-EBK**

**LICENSE PLATE LIGHT**



**FVO-439TR**

**SAFETY CHAINS (set)**



**FVO-436TR**

**KILL SWITCH**



**FV-440TR-1**

**VENT DEFLECTOR/  
VENT PIPE  
(2 PER TRAILER)**



**FV-464TR/FV-463TR**

**TAILPIPE**



**FV-457TR**

**MUFFLER & FLEX PIPE**



**FV-458TR/FV-459TR**

**OIL TANK CAP C/W CHAIN  
(TC Approved Tanks)**



**FVO-417TR-1**

**OIL TANK FUEL GAUGE**



**FVO-416AGTR-1**

**BATTERY & TRAY/HARNESS**



**FV-460TR/FV-461TR**

115V GFI WEATHERPROOF  
CASE & 115V GFI  
RECEPTACLE & WEATHER  
PROOF CLEAR IN-USE GFI  
PVC COVER



FV-454TR-1

FV-455TR-1

FV-455TR-2

DISTRIBUTION PANEL  
(PANEL ONLY)



FV-451TR

20AMP BREAKER 2 POLE  
15AMP BREAKER 2 POLE



FV-466TR

## CONTROL PANEL

MAGNETIC SWITCH



FVO-426TR

TEMPERATURE GAUGE



FVO-425TR

OIL PRESSURE GAUGE



FVO-427TR

VOLT METER



FVO-429TR

HOUR METER



FVO-430TR

IGNITION SWITCH



FVO-428TR

## YANMAR PARTS

OIL FILTER - YANMAR



FVO-440TR

FUEL FILTER - YANMAR



FVO-441TR

FUEL SCREEN - YANMAR



FVO-442TR

SLAVE SOLENOID- YANMAR



FVO-443TR

BLOCK HEATER - YANMAR



FVO-444TR

FUEL SOLENOID - YANMAR



FVO-431TR

ANTIFREEZE RESERVOIR -  
YANMAR



FVO-445TR

DIODE - YANMAR



FVO-433TR

FAN BELT - YANMAR



FVO-446TR

**AIR FILTER - YANMAR**



**FVO-447TR**

**ALTERNATOR - YANMAR**



**FVO-448TR**

**STARTER - YANMAR**



**FVO-449TR**

**KUBOTA PARTS**

**SOLENOID POWER TIMER -  
KUBOTA**



**FVO-450TR**

**OIL FILTER- KUBOTA**



**FVO-451TR**

**FUEL FILTER- KUBOTA**



**FVO-452TR**

**FUEL SOLENOID- KUBOTA**



**FVO-453TR**

**LIFT PUMP - KUBOTA**



**FVO-454TR**

**SLAVE SOLENOID - KUBOTA**



**FVO-455TR**

**FAN BELT - KUBOTA**



**FVO-456TR**

**AIR FILTER - KUBOTA**



**FVO-457TR**

**ALTERNATOR- KUBOTA**



**FVO-458TR**

**STARTER - KUBOTA**



**FVO-459TR**

**ANTIFREEZE RESERVOIR -  
KUBOTA**



**FVO-460TR**

**LOW COOLANT LEVEL  
SHUTDOWN SWITCH  
YANMAR/KUBOTA**



**FVO-461TR**

**HEATER PARTS**

**HIGH LIMITS**



**FV-406 – 250 F  
FV-437 - 150 F**

**ADJUSTABLE FAN  
LIMIT**



**FV-407A**

**TOGGLE SWITCH**



**FV-409TR**

**POWER  
INDICATOR LIGHT**



**FV-450**

**RED LIGHT**



**FV-411**

**THERMOSTAT  
CONNECTION**



**FV-414B**

**IGNITION CONTROL**



**FV0-C700-1029**

**PHOTO CELL**



**FV0-20132573**

**FUEL PUMP**



**FV0-20136488**

**FAN MOTOR**



**FV0-C7001034**

**ELECTRODE ASSEMBLY**



**FVO-3005891**

**OIL NOZZLE**



**FV-435B 2.00 X 60W**  
**FV-435WC 1.75 X 60W**

**OIL FILTER- COMPLETE**



**FVO-418**

**OIL FILTER INSERT**



**FVO-419**

**FAN MOTOR**



**FV-401TR**

**FAN BLADE**



**FV-402TR**

**FUEL LINES**



**Please Measure – SUPPLIER HEATER 1**  
**Please Measure – RETURN HEATER 1**  
**Please Measure– SUPPLY TO HEATER 2**  
**Please Measure – RETURN HEATER 2**